



Applied GMC 800-752-7502

Installation Instructions for GMC Wings

- Temporarily attach the Wing to the assembled bracket.
- Center the wing in the opened window and hold the bracket against the coach rail. Mark the lower mounting hole. Now remove the assembly and drill a #29 hole one half inch (1/2") deep and tap using an 8-32 tap.
- Remove the Wing from the bracket and attach the bracket to the coach; then mark the top hole. Swing bracket aside, drill and tap the top hole.
- Finish mounting bracket to coach.
- Attach Wing to the bracket but DO NOT over tighten the wing screws. Be sure to put the wing in the correct orientation. The distance from the holes to the front of the wing will be the shorter length.
- Adjust pivot screws just tight enough to hold position.
- To get maximum benefit of the wing; rotate the wing to touch the window, and slide the window to the edge of the wing. Now you can move the window slightly to adjust the airflow where desired.